



1. Strip cable jacket.



Determine wiring scheme. Dress all 4 pairs (8 wires).



 Insert jack in JackRapid front first with IDC slots facing blades of JackRapid.

DRESS. PRESS. SUCCESS. It's that simple!

Never again punch into the palm of your hand or through drywall.

The latest innovation in Category 5(e) jack installation is here! Introducing the JackRapid™ punchdown tool, a unique, patented, 8- or 6-place jack termination tool. Save time and increase accuracy by seating and terminating all wires at once with a simple squeeze of the handle.

High Quality Terminations

- Built-in bed helps hold jack in place.
- Eliminates error during terminations.
- No more compromised connections and wasted jacks.

Cuts Installation Time

- Easy-to-use handle, seats and cuts all wires at once.
- Increases productivity install jacks 8 times faster.

Simple, One-handed Operation

- Reduce hand fatigue one squeeze terminates all pairs!
- Virtually error-free terminations.

Wall-Friendly

Unique design easily accommodates close-to-wall installations – no slack, no problem!

The JackRapid tool will be available soon. Ask your favorite distributor.

Find a distributor, get the latest info on Harris tools and test sets: www.testsets.harris.com • 800-437-2266 toll free



 Ensure jack is completely and securely inserted in jack holder bed with IDC slots facing the blades.



5. Pull trigger completely.



Wires will be seated and cut for a solid termination.



 Release handle and remove jack from JackRapid tool. Visually verify proper termination.

